

## MOBITEK S80 QUICK INSTALLATION GUIDE


**Step 1:** SIM card size should be standard. If not, use adapter to change size.



**Step 2:** Follow the correct direction to insert SIM Card.

**Step 3:** DO NOT plug the USB cable into PC. Install USB driver from the MOBITEK thumb drive, restart computer then connect modem to PC via USB port.

**Step 4:** Ensure that the **red LED is blinking**, then go to "Device Manager", connected modem is listed under "Ports (Com & LPT)" as **Sierra Wireless AT Command Port (UMTS)**. In this example, modem is connected to COM port number 7



Note: if you are not using *SMS Gateway Development Kit*, the default baud rate is **115200**.

To request for support, please write to support@mobitek.my